

**pore**<sup>®</sup>  
enrichment

**5** YEAR  
WARRANTY

# PUREBLISS™ Luxury Towel Warmer



**USER MANUAL  
MODEL: PETWLWM**

## TABLE OF CONTENTS

SAFETY PRECAUTIONS .....	3-4
FCC NOTICE .....	5
INTRODUCTION & PRODUCT FEATURES.....	6
PRODUCT DIAGRAM.....	7
OPERATING INSTRUCTIONS.....	8-10
PRODUCT SPECIFICATIONS.....	11
CLEANING & MAINTANENCE.....	11
WARRANTY & PRODUCT REGISTRATION.....	12

## SAFETY PRECAUTIONS



READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING.

All of the safety and operating instructions should be read, adhered to, and followed before the product is operated.



**WARNING:** To reduce risk of fire, electric shock, or serious injury to persons when using the appliance, adhere to the following basic precautions:

- Always unplug the product from the electrical outlet immediately after use.
- Do not use this appliance for anything other than its intended use.
- Do not place or store the product where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for a product that has fallen into water. Unplug it immediately.
- Care should be taken so that objects do not fall into and liquids are not spilled onto the product.
- This product should never be left unattended when plugged in.
- Close supervision is necessary when this product is used near children or disabled persons.
- Use this product only for its intended use as described in this manual
- Never operate this product if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped in water.
- Keep cords away from heated surfaces. Do not let the cord hang over the table or counter edge.
- Do not use outdoors.
- Do not put 100% wool or silk goods into the machine to avoid high temperature damage.

## SAFETY PRECAUTIONS (CONT'D)

CAUTION! HOT SURFACE - DO NOT TOUCH

CAUTION: INTERIOR SURFACE IS HOT AFTER USE. TO PREVENT ANY BURNS, AVOID CONTACT WHEN TAKING OUT WARMED ITEMS.



WARNING: TO REDUCE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

FOR DRY FABRIC ITEMS ONLY. DO NOT LOAD WET TOWELS IN UNIT.

HIGH HEAT! DO NOT LOAD SILK, WOOL, LEATHER, OR SYNTHETIC FABRIC.

CAUTION! HOUSEHOLD USE ONLY. DO NOT IMMERSE IN WATER.

## FCC NOTICE

### Model: PureBliss Luxury Towel Warmer (PETWLWM)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Pure Enrichment  
2803 S Yale St.  
Santa Ana, CA 92704  
pureenrichment.com

The product is protected against unauthorized use. DO NOT modify it without the authorization of the manufacturer, or the user's authority to operate could be voided.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## INTRODUCTION

Thank you for purchasing the PureBliss™ Luxury Towel Warmer from Pure Enrichment. This modern and sleek towel warmer is designed for warming everyday cotton items like towels, robes, throw blankets, clothing, and more for a blissful experience.

## PRODUCT FEATURES

PureBliss is designed with many features that make it the ideal solution for warming up your towels and much more.

### One-Button Touch Control

Easily turn on and cycle through the timer heat settings with the intuitive one-button touch control panel.

### 4 Timer Heat Settings

Select between 4 different timer modes to heat up items to the ideal temperature.

- 15 Minutes
- 30 Minutes
- 45 Minutes
- 60 Minutes

### Lid with Handle

Easily remove and insert the lid to ensure a thorough warming cycle.


### Built-In Cord Organizer

The sleek stand doubles as a cord organizer when you are not using the product.

### Audible Feedback

The product delivers an audible beep when selecting heat timer settings or after the warming cycle is complete.


## PRODUCT DIAGRAM



## OPERATING INSTRUCTIONS

1. Carefully remove the product from the box and plastic bag.
2. Plug the product into an electrical outlet. The indicator light will flash for 1 second and turn off.
3. Press and hold the power button to turn the product on or off.

### One-Button Touch Control Panel Overview



### Selecting the Timer Mode

The default mode when turned on will be set to the 15-minute timer. Continue pressing the power button to go through the timer options one by one. The indicator light for each timer option will light up when selected.

- 1st Press = 30 minutes
- 2nd Press = 45 minutes
- 3rd Press = 60 minutes
- 4th Press = Returns to 15 minutes

After selecting a timer setting, the respective timer indicator light will flash for 3 seconds and begin the warming cycle.

## OPERATING INSTRUCTIONS (CONT'D)

### Instructions for Using the Towel Warmer

The Towel Warmer has a capacity of 20 liters and is capable of warming up to two extra-large bath towels measuring 40" x 70", three regular bath towels measuring 30" x 56", or a large throw blanket measuring 50" x 60". It is also suitable for warming smaller cotton items including pillow cases, pajamas, and socks.

**NOTE:** The Towel Warmer functions by heating up the cylinder walls, not the bottom floor. If a small item is placed inside and does not touch the cylinder wall, it may not heat completely.

### Item Restrictions

Because the inside of the warming bin gets very hot, certain materials should NOT be warmed inside this product. **Only items that are 100% cotton or cotton blend are recommended for use with this product.**

The following materials CANNOT be used in the towel warmer: silk, wool, leather, items with feathers (down jacket), plastics/rubbers (slippers with plastic/rubber soles), items with metal zippers or buttons.

### Using the Towel Warmer

1. Place the Towel Warmer on a dry, level, hard surface.
2. Insert the power cord into the electrical outlet.
3. Place **ONLY DRY** items inside. Close the lid.
4. To turn on the PureBliss Luxury Towel Warmer, press and hold the power button.
5. The 15-minute timer indicator light will flash on as the default timer setting. Press the power button to switch between the multiple timer options.
6. Once a timer option is selected, the indicator light will flash for 3 seconds and begin to heat up items. The indicator light will remain on throughout the warming process.

## OPERATING INSTRUCTIONS (CONT'D)

7. After the warming cycle is complete, the indicator light will turn off and an audible beep will sound to alert you. The product will turn off automatically.
8. When finished using the Towel Warmer, unplug it from the electrical outlet.

To ensure items are fully heated, we recommend leaving them inside the Towel Warmer for a few minutes after the timer turns off.



### WARMING TIP

Place a hand towel at the bottom of the warming bin. Then, add the items you want to warm on top of that. Slightly elevating your items ensures they touch the sides of the warming bin where they can be evenly heated.

### Additional Tips

Even after a timer option is selected, you can still adjust the timer option to add more time by pressing the power button. The timer indicator light will flash for 3 seconds and begin to warm items.

If you accidentally press the power button by mistake during a set timer period, the product will switch to the next timer setting and start the new timer.



**WARNING: When removing items out of the Towel Warmer, be extremely careful not to touch the interior surface of the product. May result in burns.**

## PRODUCT SPECIFICATIONS

Size	11.8" (W) x 11.8" (D) x 21.6" (H)
Capacity	20L
Weight	9.9 lbs.
Heating Time	15 minutes (default) 30 minutes 45 minutes 60 minutes
Power	120V AC, 60Hz, 480W

## CLEANING & MAINTENANCE

Keep the product in a ventilated, dry environment and keep away from heat. Always turn off and unplug the product from the outlet when not in use and before cleaning. After the machine has been used and cooled down, wipe the inside of the warming bin with a dry cloth to keep it clean. DO NOT use water to clean the inside of the towel warmer.

## **WARRANTY**

PureBliss comes with an industry-leading 5 Year Warranty that begins on the date of purchase.

The warranty applies to the towel warmer and necessary parts and labor relating thereto. The warranty does not apply to damage resulting from failure to follow the operating instructions, accidents, abuse, alterations, or disassembly by unauthorized individuals.

## **PRODUCT REGISTRATION**

To ensure your full warranty, and to receive product updates and streamlined customer support, remember to register your product at:

[pureenrichment.com/productregistration](http://pureenrichment.com/productregistration)

## **ARE YOU 100% SATISFIED?**

If you have product questions or concerns, don't hesitate to contact us directly at:

Email: [help@pureenrichment.com](mailto:help@pureenrichment.com)

Phone: (657) 275-3737

(Available Monday-Friday, 8am-5pm PST)

Pure Enrichment has an award-winning warranty, exchange, and customer service program that guarantees hassle-free solutions to any issue you might have within 24 hours!



Santa Ana, CA 92704  
[pureenrichment.com](http://pureenrichment.com)